MOCAL

Rover V8 oi! pump cover

incorporating take offs for remote oil filter and oil cooler

Fitting instructions

casting.

Remove existing filter head assembly, remove oil pressure relief valve, spring and threaded cap clean thoroughly and refit in Mocal cover using new copper washer provided.

Fit cover to engine using new paper gasket and existing bolts.

If you have more than 2.5" of space beyond the port faces use 1/2 BSP adaptors with rubber sealing rings if not you will have to use taper fit adaptors either 1/2 BSPT or NPTF will fit but do use a thread seal and be careful not to overtighten to avoid cracking the

The tapping near "out" port (connect to in port of remote filter) is 1/2 UNF to fit existing pressure switch, if gauge is required as well use T piece or boss adjacent to pressure relief port may be drilled and tapped, we suggest 1/8NPTE.